



Datasheet Sallegra® Multitouch Satellite Display



swissmade 👽

Sallegra® Multitouch Satellite Display

- Display of hotel room status for hotel staff (Do not distrub, Clean room, etc.)
- Display of hotel room alarm status (Alarm, Fire alarm, etc.)
- Display of hotel room number
- Hotel room bell via touch display
- All graphics are customizable and extendable

Take your hotel technology to a whole new level with the new Sallegra® Multitouch Satellite Display. The 2.8" small display is installed at the entrance door of a hotel room and is simply connected via USB to the Sallegra® multitouch display installed in the hotel room. There it replaces the classic doorhanger, which is used to display the room status. The hotel guest can easily set the room status via the Sallegra® Multitouch display in the hotel room, which is then displayed on the Sallegra® Multitouch satellite display on the room door. Of course, if desired, it indicates that the room should be cleaned or that the guest does not want to be disturbed. But it can also be used as a discreet doorbell via the touch display. In the event of an alarm (e.g. fire alarm), all status displays of the hotel room are also shown on the Sallegra® Multitouch Satellite Display and the hotel staff can already recognise the status of the room before the door.

Tecnical data	
Requirements	
	Sallegra® Hotel Controller
	Sallegra® Multitouch display 7" or 10"
Display	
	2,8" TFT display with Touchscreen, resolution/graphics 320x240 pixels at 16 Bit colour depth
Supply voltage	
	5V DC via USB connection of the Sallegra® Multitouch display
Power consumption	
	100mA
Interface	
	Micro-USB
Housing / mounting type	
	Chrome steel brushed (front side), very noble
	Flush mounting

All specifications subject to change without notice or liability to provide changes to prior purchasers. Information and specifications published here are current as of the date of publication of this document. We reserve the right to change or modify specifications without prior notice. www.satelco.ch * Warranty ex works, normally 24 months, fixed at order. Information is current as of the date of publication. Subject to errors and modifications. / NOTE: Internal connections refer to connections inside the unit, generally mounted across a pin-header. External connections refer to those outside the box. Once mounted, only connections described as "front accessible" can be accessed by the customer.

1